

ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


CAUTIONS :

1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
3. Keep all hardware part out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PC
B	TABLE LEG (L & R)	2 PCS
C	TABLE LEG SUPPORT (UPPER)	1 PC
D	TABLE LEG SUPPORT (LOWER)	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 25MM 	3 PCS
2	SPRING WASHER 1/4" 	3 PCS
3	FLAT WASHER 1/4" 	3 PCS
4	JCN NUT M8 X 17MM 	2 PCS
5	BOLT SCREW M8 x 145MM 	2 PCS
6	M5 ALLEN KEY 	1 PC
7	M4 ALLEN KEY (BALL SHAPE) LONG 	1 PC
8	WOOD DOWEL 10 x 35MM 	2 PCS
9	BASE GLIDE C99(Screw) M6 x 23 	3 PCS


STEP 1 :




STEP 2 :




STEP 3 :



STEP 4 :



STEP 5 :



ASSEMBLY COMPLETED